

baby&child

RESTORATION HARDWARE

Thank you for selecting Restoration Hardware Baby & Child lighting. Our assortment is crafted with the highest quality materials that coordinate perfectly with our Baby & Child bedding collections, making it easy to create an elegant nursery or child's bedroom.

PARTS ENCLOSED: HARDWARE INCLUDED:

- | | |
|------------------------|--------------------------------|
| (A) Mounting plate (1) | (a) Green ground screw (1) |
| (B) Canopy (1) | (b) Plastic wire connector (2) |
| (C) Fabric Shade (1) | (c) Finial (1) |
| (D) Socket Cup (1) | (d) Mounting screw (2) |
| (E) Diffuser (1) | (e) Plate screw (2) |
| | (f) Cord screw (1) |

IMPORTANT SAFETY INSTRUCTIONS:

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.

This fixture has been rated for up to (1) 100-watt maximum TYPE A bulb. To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off lamp and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.

Keep flammable materials away from lit bulb.

□

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Turn OFF power to the junction box where the lamp will be installed.
3. Please note that fabric shade (C) and Diffuser (E) are shipped unassembled. First insert one 100 Watt Type A bulb (not included) into threaded socket then place the Fabric shade (C) onto the Socket cup (D) and insert the Cord screw (f) on the threaded tube of Socket Cup (D) and turn clockwise to tighten it.
4. Place Diffuser (E) under the Socket Cup (D) and pull the threaded tube through the hole of the Diffuser (E), finally, insert the Finial (c) on the thread tube of Socket Cup and turn clockwise to tighten it.
5. Attach Mounting plate (A) to the outlet box using the Mounting screws (d) and tighten it.
6. Once they are threaded together, attach the ground wire from the fixture to the ground junction box wire from the outlet box (usually green or bare wire), or wrap the ground wire around the green ground screw (a).
7. Connect the hot wire to the hot junction box wire (usually black or smooth) with a plastic wire connector (b) and wrap the connection with electrical tape. Connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a plastic wire connector (b) and wrap the connection with electrical tape.
8. Attach the Canopy (B) to the Mounting plate (A) using Plate screws (e) and tighten it .
9. Restore power to the junction box and test lamp fixture.
10. Installation is complete.

CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp.

JUST WIPE CLEAN WITH SOFT CLOTH.

ADLER PENDANT

Direct Wire Installation

