

Step 1:

1.Put the top (A) on a flat floor amd turn the desk upside down.(Noted: the floor must be covered with protective material so that the item is not touching the floor directly).

- 2. Position the leg (B) over the top (A) and align the leg onto given hole on the top (A) as shown in the sketch.
- 3. Insert the Allen bolt (4) and tighten it using the Allen key (3).
- 4. Repeat the procedure with the other leg.

Step 2:

1. Position the metal pole(C) and inset it to the clamp on the sidebeam of the leg (B).

2. Insert the long Allen bolt (2),nut A(4) and tighten the bolt using allen key(3) as the shown in the sketch.

3. Connect the two metal poles with the short Allen bolt (5) and nut B (6), tighten the bolt using allen key(3) as the shown in the sketch.

Turn the desk up to complete.

Page 1 of 2

