

Classic Wall-Mount Tent Canopy Hardware






WARNING: ADULT ASSEMBLY ONLY OWING TO THE PRESENCE OF SMALL PARTS.

Customer Service-If you are missing parts or have any questions about this product, Please contact us at: 1-800-762-1751

- Please read all instructions before beginning assembly.
- Professional installation recommended.
- Save all packing materials until assembly is complete to avoid accidentally discarding parts or hardware.

Parts & Hardware Enclosed

- (3) Fixed rods 
- (3) Wall brackets 
- (9) Phillip screws 1.5" 

- (3) Finials 
- (9) Plastic anchors 1.5" 

You will Need

Phillips Screwdriver
Drill with a 0.25" bit

Assembly & Installation

Hardware accommodates any bed or crib size; you choose how wide and high to install the Fixed Rods. Once installed, the rods support a single fabric panel draped from side to side across the head of the bed or over the length of a crib.

1. Center Fixed Rod over the crib or bed. Mark appropriate placement of Wall Bracket with a pencil.
2. Using a drill with a 0.25" bit, pre-drill screw holes into the wall where marked. Install the first Wall Bracket into the marked location with 3 Screws. If mounting into drywall, use the Anchors for added support. If possible, installation into wall studs is recommended. Figure 1
3. Determine placement of remaining 2 Fixed Rods by inserting the rods into the pole pockets of the drapery panels. Drape center of the panel over the middle rod and mark the placement of the other two rods on either side on the wall with a pencil.
4. Install remaining two Wall Brackets on each side of the center Wall bracket, as in Step 2, using a level to ensure they are even.
5. Thread the rods onto the Wall Brackets and the finials into the rods. Figure 2
Rods are designed to hold up to 30 lbs. of fabric.

