

Classic Swag Canopy Hardware





WARNING: ADULT ASSEMBLY ONLY OWING TO THE PRESENCE OF SMALL PARTS.

Customer Service-If you are missing parts or have any questions about this product, Please contact us at: 1-800-762-1751

- Please read all instructions before beginning assembly.
- Professional installation recommended.
- Save all packing materials until assembly is complete to avoid accidentally discarding parts or hardware.


Parts & Hardware Enclosed


(2) Adjustable rods 

(4) Ceiling brackets 

(12) Phillip screws 1.5" 

(12) Plastic anchors 1.5" 

(2) Plastic c-rings 

(4) Finials 

(1) Allen wrench 

You will need

Phillips Screwdriver
Drill with a 0.25" bit

Assembly & Installation

Determine width of Adjustable Rods prior to installing the Ceiling Brackets. Note: Drapery panel needs to fit between each Ceiling Bracket.

1. The first rod will be placed along the back of the crib or bed. If positioned against the wall, please allow clearance for the Ceiling Brackets; the second rod will be placed away from the first rod at the front of crib or bed. The closer rods, the deeper the swag of the drapery panel; the farther apart, the tauter the panel. Suggested distance between rods is as follows to hang over the depth of most cribs or beds: Crib: 33", Twin: 75", Full: 75", Queen: 80".
2. Determine width of rod placement. Mark appropriate placement of each Ceiling Bracket with a pencil. Using a drill with a 0.25" bit, predrill screw holes into the ceiling where marked. Install the first Ceiling Bracket into the marked location with Screws. If mounting into drywall, use the Dry-Wall Bolts for added support. If possible, securing hardware into wall studs is recommended. Figure 1
3. Rest the rod in the bracket and extend the rod to the desired width to determine placement of second Ceiling Bracket. Figure 3
4. Install second Ceiling Bracket (See Step 2)
5. Slip a rod-pocket style canopy panel on one of the Adjustable Rods and secure rod ends into the Ceiling Brackets. The long back panel should flow behind the back of the crib or headboard. Figure 3
6. Attach the finial at each end of the Adjustable Rod, and tighten rod into place using the Allen wrench. Figure 2
Note: once the back of the drapery panel is secure, you can pull the front of the panel forward to the desired length. This will help you visually determine the placement of the second Adjustable Rod.
7. Determine placement of second Adjustable Rod. Secure using Steps 2-3.
8. Slip the other end of a rod-pocket drapery panel on the Adjustable Rod and secure rod ends into the Ceiling Bracket as noted in Steps 5-6.
9. Insert plastic c-rings in gap where rod telescopes, allowing for easy passage of drapery rings over the gap. Figure 4
Rods are designed to hold up to 30 lbs. of fabric.

