







RONSON UPHOLSTERED PARSONS TRUNDLE BED - ASSEMBLY INSTRUCTIONS  
FULL & QUEEN

**PARTS INCLUDED**

A.HEADBOARD (1)  
B.SIDE RAILS (2)  
C.FOOTBOARD (1)  
D.SLATS (4)  
E.PLATFORMS (2)  
F.TRUNDLE (1)

NO	ITEM	HARDWARE ENCLOSED	QTY
1		Allen Key (0.5cm)	1 pc.
2		Allen-Head bolts (0.8cm Dia.)	8 pcs.
3		Screws (4cm)	8 pcs.
4		Screws (3cm)	16 pcs.

**TOOLS NEEDED**

Phillips-Head Screwdriver (not included)



**ASSEMBLY INSTRUCTIONS**

Bed must be assembled by at least two people.

Please read instructions carefully before assembling bed.

Use the above parts and hardware list to identify each component.

Keep all packing materials until assembly is complete to avoid loss of smaller parts.

1. Screw the Allen Head Bolt (2) to the Headboard (A), then stand the Headboard (A) upright and attach Side Rails (B), as shown in Diagram I.
2. Repeat above procedure to attach the Footboard (C), then tighten all Allen Head Bolts (2) with Allen Key (1).
3. Place the Slats (D) on the top of the Side Rail's side slats and fasten using Screw (3), as shown in Diagram II.
4. Lay the Platform Panel (E) on the top of the slats (D), then screw with screw (4), as shown in Diagram III.
5. Push the Trundle (F) into the Bed Base under Side Rails (B), making sure the Trundle (F) panels are flush with Side Rails (B).

**CARE INSTRUCTIONS**

Spot clean only with a soft, damp cloth.

