# RHBABY&CHILD

## SYDNEY UPHOLSTERED HEADBOARD INSTRUCTIONS

#### PARTS INCLUDED

A [1] HEADBOARD

B [1] BED FRAME (NOT INCLUDED)

NO.	ITEM	DESCRIPTION	QTY.
1		Bed Hooks (Left & Right)	2 pcs.
2	(111111111)	Bolts	4 pcs.
3		Hex Nuts	4 pcs.
4	0	Lock Washers	4 pcs.

#### **ASSEMBLY INSTRUCTIONS**

- 1. Insert one bed hook (1) (hooks pointing upward) into headboard (A) bottom and tap bed hook (1) securely into place.
- 2. Determine which set of slots in bed hook (1), bed frame (B) should be bolted to, so that headboard (A) legs "float" above floor.
- 3. Remove bed hook (1) from headboard (A) and loosely attach both bed hooks (1) to bed frame (B), though slots determined previously, using bolts (2), lock washers (4) and hex nuts (3) provided.
- 4. Place headboard (A) on bed hooks (1) and tighten bolts (2) securely, see drawing below.

#### **CARE INSTRUCTIONS**

- 1. Spot clean only with a soft, damp cloth.
- 2. Do not use abrasive cleanser.

### IMPORTANT SAFETY INSTRUCTIONS

- 1. Please read all instructions carefully before assembling.
- 2. For your safety, assembly by two or more adults is strongly recommended.
- 3. Keep instructions for future use.
- 4. Use only vendor supplied hardware to assemble, using unauthorized hardware could jeopardize the structural integrity of the item.

