




**CARVER UPHOLSTERED BED**

**PARTS INCLUDED**

- A [1] Headboard
- B [2] Side Rail
- C [1] Footboard
- D [1] Slat Roll
- E [1] Center Support Slat
- F [1] Center Support Slat Foot (with adjustable glide)

NO.		DESCRIPTION	Qty
1		Screw(3cm)	32 Pieces
2		Screw(5cm)	2 Pieces
3		Allen Key	1 Piece

**TOOLS NEEDED**

Phillips Screwdriver (not included)



**ASSEMBLY INSTRUCTIONS**

Bed must be assembled by at least two people.  
Please read instructions carefully before assembling bed.  
Use the above parts and hardware list to identify each component.  
Keep all packing materials until assembly is complete to avoid loss of smaller parts.

1. Stand the Headboard (A) upright and attach Side Rails (B), as shown in Diagram I.
2. Repeat above procedure to attach the Footboard (C).
3. Attach the Center Support Slat Foot (F) to the Center Support Slat (E) as shown in Diagram II.
4. Attach the Center Support Slat (E) to the U shape wood blocks on Side Rail (A), tighten with Long Srew (2) as shown in Diagram III.
5. Place the Slat Roll (D) into the cleats on the inside of the Side Rails (B).  
Screw the ends of the slats to the cleats using Screws (1), as shown in Diagram IV.

## CARE INSTRUCTIONS

1. Spot clean only with a soft, damp cloth.

