

baby&child


RESTORATION HARDWARE

Thank you for purchasing Restoration Hardware Baby and Child lighting. Our assortment is crafted with the highest quality materials that coordinate perfectly with our Baby & Child bedding collections, making it easy to create an elegant nursery or child's bedroom.

PARTS ENCLOSED:

- (A) FINIAL
- (B) HARP
- (C) HARP SADDLE
- (D) BASE
- (E) PROTECTIVE PLASTIC CAP
- (F) POLARIZED PLUG

HAYDEN TABLE LAMP



IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (1) 100W MAX. Type A, medium base bulb. To avoid risk of fire, do not exceed the recommended wattage.

WARNINGS:

Turn off power (unplug from the wall outlet) before replacing the bulb(s), making sure the bulb(s) had sufficient time to cool down.

DO NOT subject the lamp to any shock while lit as shattering of bulb may result.

TO ASSEMBLE:

1. Remove all parts carefully from carton. Do not throw away any parts.
2. Remove all packaging material from lamp.
3. Place base (D) on level surface.
4. Place harp (B) into harp saddle (C) by squeezing harp (B) inward and placing into the openings of saddle (C).
5. Insert one (1) 100W MAX. Type A, medium base bulb into socket.
6. Place center ring of the shade spider (SHADE SOLD SEPARATELY) onto threaded nipple, located on top of harp (B).
7. Thread finial (A) onto exposed section of nipple to secure shade (SHADE SOLD SEPARATELY) to lamp.
8. Remove protective plastic cap (E) from polarized plug (F).
9. Insert polarized plug (F) into wall outlet.

CARE INSTRUCTIONS:

To clean, use a soft cloth only. DO NOT use any chemical or abrasive cleaners.