

baby&child

RESTORATION HARDWARE

VINTAGE SCHOOLHOUSE PLAY TABLE LG

ASSEMBLY INSTRUCTIONS:

1. Carefully unpack the contents of the carton and place the top upside down on a non marring surface (Fig.1)
2. Place the leg as shown in Fig.2 & Fig.3 (match the bolts on the leg with the holes on the inside of the table)
3. Insert the washers and the nuts (provided) as shown (Fig.4 & Fig.5). Tighten the nuts with the wrench (provided).
4. Repeat step no. 2 & 3 for all the legs
5. Once all 4 legs have been secured to their ends, place the table upright. Assembly is complete. (Fig.6)




Fig.1



WRENCH




Fig.2




Fig.3




Fig.4




Fig.5




Fig.6

CARE INSTRUCTIONS:

1. Clean periodically by wiping with a soft clean cloth.
2. Do not use abrasive cleaners, chemical cleaners or metal polisher. The metal sheet has a protective lacquer finish that could be damaged by chemical or abrasive cleaning agents.