

baby&child

RESTORATION HARDWARE

Thank you for selecting Restoration Hardware Baby & Child lighting. Our assortment is crafted with the highest quality materials that coordinate perfectly with our Baby & Child bedding collections, making it easy to create an elegant nursery or child's bedroom. Each item's surface is sealed which eliminates the need for polishing and ensures a lasting finish for years to come.

PARTS ENCLOSED:

- (A) Lamp clip
- (B) Adjustable handle
- (C) Bulb
- (D) Socket
- (E) Adjustable lamp arm.

IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (1) 13 W CFL bulb (included) or (1) 40 W Type A bulb. To avoid the risk of fire, do not exceed the recommended wattage.

Typesetter's Task Clip Lamp

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.

Keep flammable materials away from lit bulb.

DO NOT REMOVE THE CARDBOARD INSULATOR SURROUNDING THE SOCKET.
THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Open the lamp clip (A) and clip on the lamp to the table edge or where suitable for clip.
3. Insert (1) 13W CFL bulb or (1) 40W-max Type A bulb (C) into the threaded socket (D).
4. Set the lamp shade to the desired direction by carefully adjusting the adjustable handle (B) to the left and right and set the lamp body to the desired position by carefully adjusting the adjustable lamp arm (E).
5. Plug into proper electrical outlet and test fixture.
6. Assembly is complete.

CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp.
JUST WIPE CLEAN WITH SOFT CLOTH.

