

baby&child


RESTORATION HARDWARE

Thank you for purchasing Restoration Hardware Baby & Child lighting. Our assortment is crafted with the highest quality materials that coordinate perfectly with our Baby & Child bedding collections, making it easy to create an elegant nursery or child's bedroom. The item's surface is sealed, which eliminates the need for polishing and ensures a lasting finish for years to come.

PARTS ENCLOSED

- (A) Lamp Base (1)
- (B) Saddle (1)
- (C) Harp (1)
- (D) Finial Screw Plate (1)
- (E) Finial (1)
- (F) CFL Bulb (1)

FRANCIS FLOOR LAMP



IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into outlet, do not force it, contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted in to the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (1) 100-watt maximum TYPE A standard bulb or 23 W CFL bulb. To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

- All wires are connected.
- Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- Do not connect electricity until your lamp is fully assembled.
- To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on or look directly at lit bulb.
- Keep flammable materials away from lit bulb.

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Insert Harp (C) in to the saddle (B).
3. Insert CFL bulb (F) in to threaded socket.
4. Remove the finial (E) by unscrewing in counter clockwise direction.
5. Place the shade(sold separately) on finial plate (D).
6. Reattach the finial (E) and tighten to secure the shade by screwing in a clockwise direction.
7. Plug in to proper electrical outlet and test fixture.
8. Assembly is complete.

DO NOT REMOVE THE CARDBOARD INSULATOR SURROUNDING THE SOCKET

CARE INSTRUCTIONS:

Wipe clean with a soft, dry cloth.