



## ELLIS SWING-ARM FLOOR LAMP WITH SHADE - ASSEMBLY INSTRUCTIONS

### PARTS ENCLOSED:

- |                 |                 |
|-----------------|-----------------|
| (A) LED bulb    | (F) Top post    |
| (B) Socket ring | (G) Metal ring  |
| (C) Lamp shade  | (I) Bottom post |
| (D) Socket      | (J) Lamp base   |
| (E) Swing arm   |                 |

### IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one prong is wider). If the plug does not fit securely into your outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (1) 100-Watt maximum Type A standard incandescent lightbulb (not included) or one (1) 23-Watt maximum compact fluorescent lightbulb (not included) or one (1) 12-Watt maximum LED lightbulb (not included). (1) 9W LED lightbulb is included with this lamp. To avoid the risk of fire, do not exceed the recommended wattage.

### WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing lightbulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.  
Keep flammable materials away from lit bulb.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.

### WARNING: STRANGULATION HAZARD

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3 years of age.

### TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic coverings.
2. Place the lamp base (J) on the floor carefully.
3. Screw the bottom post (I) onto the lamp base (J).
4. Place the metal ring (G) onto the bottom post (I), and screw the top post (F) onto the bottom post (I).
5. Screw the swing arm (E) onto the top post (F).
6. Place the lamp shade (C) onto the socket (D), and tighten using the socket ring (B).
7. Insert the bulb (A) into the socket (D). Turn clockwise until secure.
8. Plug into proper electrical outlet and test fixture.
9. Assembly is complete.

### CARE INSTRUCTIONS:

Do not use polishes or cleaners on the lamp.  
Wipe clean with a soft, dry cloth.

