

baby&child

RESTORATION HARDWARE

Thank you for selecting Restoration Hardware Baby & Child lighting. Our assortment is crafted with the highest quality materials that coordinate perfectly with our Baby & Child bedding collections, making it easy to create an elegant nursery or child's bedroom. The item's surface is sealed, which eliminates the need for polishing and ensures a lasting finish for years to come.

PARTS ENCLOSED:

- (A) Mounting plate (1)
- (B) Backplate (1)
- (C) Socket (1)
- (D) Bulb (1) (included)

HARDWARE INCLUDED:

- (a) Green ground screw (1)
- (b) Plastic wire connector (3)
- (c) Wall screw (2)
- (d) Wall anchor (2)
- (e) Wall plate screw (2)

IMPORTANT SAFETY INSTRUCTIONS:

This fixture must be installed by a licensed electrician.

This fixture has been rated for up to (1) 40-watt maximum TYPE B candelabra bulb (included).

To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your fixture is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.

Keep flammable materials away from lit bulb.

ELSA CRYSTAL SCONCE

Direct Wire Installation

THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Turn OFF power to the junction box where the lamp will be installed.
3. Insert (1) 40-watt Type B candelabra bulb (D) (included) into the socket (C).
4. Use a screwdriver to install a wall anchor (d) into the wall. Continue rotating the anchor until its wide flange is flush with the wall surface. Do not over-tighten. Repeat with the other anchor.
5. Use a screwdriver to secure the provided wall screws (c) into each installed anchor. Rotate the screw until the head is about 1/4 inch from the wall.
6. Unscrew the wall plate screws (e) in the mounting plate (A) and separate the backplate (B) from the mounting plate (A).
7. Insert the junction box wires through the central hole of backplate (B).
8. Connect the hot wire on the fixture (labeled with an "L") to the hot junction box wire (usually black or smooth) with a plastic wire connector (b) and wrap the connection with electrical tape. Connect the neutral wire on the light fixture (labeled with an "N") to the neutral junction box wire (usually white or ribbed) with a plastic wire connector (b) and wrap the connection with electrical tape.
9. Attach the ground wire from the fixture to the ground junction box wire from the outlet box (usually green or bare wire), Or wrap the green ground wire around the green ground screw (a).
10. Hide all the wires neatly inside the mounting plate (A). Put the backplate (B) into the mounting plate (A) and use the wall plate screws (e) to secure.
11. Aim the two holes on backplate (B) at the installed wall screws (c). Hang the fixture on the wall.
12. Restore power to the junction box and test lamp fixture.
13. Installation is complete.

CARE INSTRUCTIONS:

Do not use polishes or cleaners on your fixture.

JUST WIPE CLEAN WITH SOFT CLOTH.

