baby&child
RESTORATION HARDWARE

IRON LEANER SHELVING SMALL

WARNING

Young children may be injured by tipping furniture, and proper installation of the mounting hardware for this item is highly recommended. When properly installed, this mounting hardware could provide protection against the unexpected tipping of this furniture piece. We recommend mounting to a wall stud if possible. Please note: this item is not designed for use as a ladder.

NO.	ITEM	DESCRIPTION	QUANTITY
1		Allen Bolt	12pcs.
2		Screw	5pcs.
3		Wall Anchor A (for concrete wall)	5pcs.
4		Wall Anchor B (for dry wall)	5pcs.
5		Long Screw	5pcs.
6		Plastic Cover	2pcs.
7		Allen Key	1pc.

PARTS INCLUDED

A [1] SHELF UNIT
B [6] CONNECTION ROD

TOOLS NEEDED

TOOLS NEEDED: Phillips Head Screwdriver (not included)

ASSEMBLY INSTRUCTIONS

Two people are recommended for easy assembly. These instructions are written assuming two people are assembling the unit.

1. Loosen bolt on the top shelf to rotate the shelf to the right position, then tighten it by using Allen Key (7).
2. Rotate the bottom three shelves to match the connection rods (B) with the shelves: longer rods go with bigger shelves and shorter rods with smaller shelves.
3. Align the holes on the connection rods with the holes on the shelves.
4. Insert the Allen Bolts (1) and tighten with the Allen Key (7) as shown in the sketch.
5. Position shelving unit in the desired location on the wall and mark where top of unit hits the wall.
6. Shelving unit attaches to wall in three locations:
   - At top of shelf unit (×2)
   - Top shelf (×2)
   - Bottom shelf (×1)





7. According to the wall material, choose the corresponding wall mounting hardware:

Concrete wall	Wall anchor A		5pcs.	Screw		5pcs.
Dry wall	Wall anchor B		5pcs.	Long screw		5pcs.
Wood wall				Screw		5pcs.

8. At each connection point, drill 1/4" pilot hole in the wall. Insert wall anchor (3 or 4) into the hole and gently tap anchor into the wall until cap prongs are embedded in wall and cap is snug against surface.
9. Insert the screw (2 or 5) into the given hole, turn screw clockwise, pressing firmly to prevent anchor from rotating. Tighten screw until resistance is felt. This will fully expand the anchor.
10. Insert the plastic cover (6) over the holes in the top of unit as illustrated, if desired.

CARE INSTRUCTIONS

1. Clean periodically by wiping the furniture lightly with a soft, clean cloth.
2. We don't recommend using abrasive or chemical cleaners as they may damage the finish on the furniture.

IMPORTANT SAFETY INSTRUCTIONS

Maximum load for each shelf:
Top shelf : 50 lbs
Second shelf : 50 lbs
Third shelf : 90 lbs
Bottom shelf : 90 lbs