

ELODIE CABINET TOPPER

⚠ WARNING: FALL HAZARD - To prevent death or serious injury from falls, always keep child within arm's reach, NEVER LEAVE CHILD UNATTENDED and always use restraining system.

This changing table is intended for use with children weighing up to 30 pounds. Elodie Cabinet Topper will be used with Elodie Cabinet (sold separately) with size 39" W x 16" D x 29" H. Cushion pad size is 32"L x 16"W x 4"H.

Do not use Elodie Cabinet or Topper if damaged or broken.

Customer Service - If you are missing parts or have any question about this product, please contact us at:
1-800-762-1751

IMPORTANT SAFETY INSTRUCTIONS:

Please read all instructions before use of the cabinet or topper.
For your safety, assembly by two or more adults is recommended.
Keep instructions for future use.

PART LIST

- A. [1] ELODIE CABINET TOPPER
- B. [1] ELODIE CABINET
- C. [2] METAL BRACKET
- D. [8] PHILLIPS WOOD SCREW

TOPPER ASSEMBLY INSTRUCTIONS

Place the cabinet topper [A] on top of the cabinet [B], and check the distance on both sides to make sure the cabinet topper is centered correctly. Secure the metal brackets [C] to the back of the cabinet [B] and to the back of the cabinet topper [A] with screws [D].

CARE INSTRUCTIONS:

- Dust often using a clean, soft, dry lint-free cloth.
- Blot spills immediately, and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives, or furniture polish on our lacquered finish.

