

EMERSON HEADBOARD

WARNING : ADULT ASSEMBLY ONLY OWING TO THE PRESENCE OF SMALL PARTS, SHARP POINTS AND EDGES

Customer Service- If you are missing parts or have any questions about this product, please contact us at :
1-800-762-1751

PART LIST


Headboard (1)


Pre-assembled bed frame (not included)

TOOLS & HARDWARE INCLUDED:

A – Allen Bolts (x6) 

C – Spring Washer (x6) 

B – Flat Washer (x6) 

D – Allen Key (x1) 

PRE-ASSEMBLY


Please read all instructions before beginning assembly.

For ease of assembly, two adults are recommended.

Save all packaging materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.

ASSEMBLY INSTRUCTIONS

1. Hold headboard upright and tilted slightly towards the faceplates of the pre-assembled bed frame.
2. Align the slot in the faceplate with the pre-drilled holes in the legs of the headboard.
3. Slide Flat washer (B), Spring washer (C) onto Allen Bolts (A) then insert Allen bolts (A) into the top hole on legs, and use Allen key (D) to tighten the bolts into legs. Repeat for all pre-drilled holes.



Thank you for your purchase

www.rhbabyandchild.com