

ASHER VANITY DESK ASHER VANITY TOPPER



WARNING: ADULT ASSEMBLY ONLY OWING TO THE PRESENCE OF SMALL PARTS, SHARP POINTS AND EDGES

Customer Service- If you are missing parts or have any questions about this product, please contact us at : 1-800-762-1751








PARTS LIST

- A [1] VANITY TOPPER
- B [1] VANITY BASE
- C [1] LEFT LEG PANEL
- D [1] RIGHT LEG PANEL

TOOLS NEEDED

- Allen Key 4mm


HARDWARE INCLUDED:

NO	DESCRIPTION		Q'TY
1	Long Bolt \varnothing 5/16" x 1-1/2"		4 pcs
2	Flat Washer \varnothing 5/16" x 19mm		4 pcs
3	Lock Washer \varnothing 5/16" x 13mm		4 pcs
4	Wood Plug \varnothing 10 x 30mm		8 pcs
5	Wood Screw 6 x 12mm		8 pcs
6	Metal Bracket		2 pcs
7	Allen Key 4mm		1 pc


ASSEMBLY INSTRUCTION

Note: Vanity desk can be assembled by one person rather easily, but if two people are available it is a bit easier and the operation will require less preparation. The instructions are written assuming one person is assembling the vanity.


Step 1. Put the 8 Wood Plugs [4] to the holes of Left Leg Panel [C] and Right Leg Panel [D]. Attach the leg panels to the Vanity Base [B] with using the Bolt [1], Lock Washer [2], Flat Washer [3] and tighten by Allen Key [7].



Step 2. Attach Vanity Topper [A] onto Vanity Base [B], place 2 Metal Brackets [6] over the pre-drilled holes on back of Vanity Topper [A] and secure it to Vanity Base [B] with 8 Wood Screws [5].



Step 3. Insert the drawer in to its place.



CLEANING INSTRUCTIONS

To maintain and protect the luster of all products, clean with a soft, damp cloth only.

www.rhbabyandchild.com

- Page 2 of 2 -