

baby&child

RESTORATION HARDWARE

Thank you for selecting Restoration Hardware Baby & Child lighting. Our assortment is crafted with the highest quality materials that coordinate perfectly with our Baby & Child bedding collections, making it easy to create an elegant nursery or child's bedroom.

PARTS ENCLOSED:

- (A) Finial (1)
- (B) Harp (1)
- (C) CFL bulb (1)
- (D) Socket (1)
- (E) Saddle (1)
- (F) Tube
- (G) Knob(1)
- (H) Square iron bar

IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (1) 13W CFL bulb or (1) 60 W standard bulb. To avoid the risk of fire, do not exceed the recommended wattage.

Evan's Telescoping Table Lamp

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.

Keep flammable materials away from lit bulb.

DO NOT REMOVE THE CARDBOARD INSULATOR SURROUNDING THE SOCKET.
THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Spread out the four square iron bar (H) and adjust the bracket of the four square iron bar until the lamp is straight.
3. Insert Harp (B) into the Saddle (E).
4. Insert CFL bulb (C), into threaded socket (D).
5. Attach the finial (A) and tighten to secure the shade.
6. Plug into proper electrical outlet and test fixture.
7. The height can be adjustable, rise or drop the tube (F) to adjust the total height, and tighten it by the knob (G).
8. Assembly is completed.

□

CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp.
JUST WIPE CLEAN WITH SOFT CLOTH.

□

