


baby&child

RESTORATION HARDWARE

Thank you for purchasing Restoration Hardware Baby and Child lighting. Our assortment is crafted with the highest quality materials that coordinate perfectly with our Baby & Child bedding collections, making it easy to create an elegant nursery or child's bedroom.

ASSEMBLY INSTRUCTIONS FOR YOUR SULLIVAN TASK LAMP



IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one blades is wider then the other). If the plug does not fit securely into outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (1) 60W MAX. Type A, medium base bulb. To avoid risk of fire, do not exceed the stated wattage.

WARNINGS:

Turn off power (unplug from the wall outlet) before replacing the bulb(s), making sure the bulb(s) had sufficient time to cool down.

DO NOT subject the lamp to any shock while lit as shattering of bulb may result.

ASSEMBLY INSTRUCTIONS:

1. Remove all parts from the box.
2. Loosen adjustment key (E) on swivel. Move lamp arm into desired position, making sure location pin on arm swivel (G) is inserted between location pins on base swivel (F), and re-tighten adjustment key (E).
3. Carefully push shade (A) onto socket cover (B). Note: Shade will "pop" into place.
4. Insert one (1) Type A, 60W MAX bulb (INCLUDED) into the socket.
5. Remove protective plastic (D) from the electrical plug (C).
6. Insert electrical plug (C) into wall outlet.

ADJUSTMENT INSTRUCTIONS:

1. Loosen adjustment keys found on lamp column and shade.
2. Adjust arm and shade to desired position.
3. Re-tighten the adjustment keys.

CARE INSTRUCTIONS:

* To clean, wipe with a soft cloth. Do not use any chemical or abrasive cleaners as they may damage the finish. *