

## ADELE PLAY TABLE

---

**WARNING :** ADULT ASSEMBLY ONLY OWING TO THE PRESENCE OF SMALL PARTS, SHARP POINTS AND EDGES

**Customer Service-** If you are missing parts or have any questions about this product, please contact us at :  
1-800-762-1751

### PART LIST

- A [1] TABLE TOP
- B [4] LEGS
- C [8] 5/16" x8mm HEXAGON NUTS
- D [8] 5/16" SPRING WASHER
- E [8] 5/16" FLAT WASHER
- F [1] ALLEN KEY

### PRE-ASSEMBLY


Please read all instructions before beginning assembly.


For ease of assembly, two adults are recommended.





Save all packaging materials until assembly is complete to avoid accidentally discarding smaller parts or hardware

### ASSEMBLY INSTRUCTIONS

1. Turn Table top (A) upside down and place on a clean padded surface, such as carpeted floor, to prevent scratches.
2. Insert Leg (B) into apron underneath, slide Flat washer (E), Spring washer (D) onto Hexagon nut (C) and use Allen key (F) to tighten the bolts into legs. Repeat this process for all legs.
3. Turn table upright.





|   |   |            |      |
|---|---|------------|------|
| C |    | Ø5/16"*8mm | 8pcs |
| D |  | Ø5/16"     | 8pcs |
| E |  | Ø5/16"     | 8pcs |
| F |  | 1/2"       | 1pc  |

#### CARE INSTRUCTIONS:

- Dust often using a clean, soft, dry lint-free cloth.
- Blot spills immediately, and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives, or furniture polish on our lacquered finish.

*Thank you for your purchase*  
[www.rhbabyandchild.com](http://www.rhbabyandchild.com)