

## BELLA TABLE LAMP - ASSEMBLY INSTRUCTIONS

### PARTS ENCLOSED:

- (A) Finial
- (B) Harp
- (C) LED bulb
- (D) Socket
- (E) Saddle
- (F) Lamp base

### IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one prong is wider than other). If the plug does not fit securely into your outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (1) 60-Watt maximum Type A standard incandescent lightbulb (not included) or one (1) 13-Watt maximum compact fluorescent lightbulb (not included) or one (1) 9-Watt maximum LED lightbulb (included).

To avoid the risk of fire, do not exceed the recommended wattage.

### WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity unless your fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it cool prior to replacing the lightbulb.

Do not touch the bulb when fixture is turned on or look directly at lit bulb.

Keep flammable materials away from lit bulb.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.

### WARNING: STRANGULATION HAZARD

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds.

Keep out of reach of children under 3 years of age.

### ASSEMBLY & INSTALLATION:

1. Carefully remove all parts from the box and remove the plastic coverings.
2. Place the lamp base (F) on the tabletop carefully.
3. Insert the Harp (B) into the Saddle (E).
4. Insert the LED bulb (C) into threaded socket (D) and turn clockwise until secure.
5. Attach the finial (A) and tighten to secure the shade.
6. Plug into proper electrical outlet and test fixture.
7. Assembly is complete.

### CARE INSTRUCTIONS:

Do not use polishes or cleaners on the lamp.

Wipe clean with a soft, dry cloth.

