

# baby&child


## RESTORATION HARDWARE

Thank you for selecting Restoration Hardware Baby & Child lighting. Our assortment is crafted with the highest quality materials that coordinate perfectly with our Baby & Child bedding collections, making it easy to create an elegant nursery or child's bedroom. The item's surface is sealed, which eliminates the need for polishing and ensures a lasting finish for years to come.

### PARTS ENCLOSED:

- (A) Wall anchor (7pcs)
- (B) Anti-tipping kit
- (C) Wall screw (7pcs)
- (D) 4W Type G Bulb (18pcs)—included

### VINTAGE ILLUMINATED OVERSIZED ARROW



### IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (18) 7W max type G bulb. To avoid the risk of fire, do not exceed the recommended wattage.

### WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

**THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE**

### WALL-MOUNT ASSEMBLY INSTRUCTIONS:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Drill 4 holes in the wall that align with the holes on the back cover of the lamp, and insert wall anchors (A).
3. Screw the 4 wall screws (C) into anchors and slide fixture onto screws.
4. Insert the (18) 4W type G bulbs (D) into the sockets.
5. Plug into proper electrical outlet and test the light.
6. Installation is complete.

If mounting to the wall, anti-tipping kit (B) attached to the top of lamp is not necessary.

### WALL LEANING ASSEMBLY INSTRUCTIONS:

1. Carefully remove all parts from the box and remove all plastic covering.
2. For safety purposes, please use anti-tipping kit (B). Pull out the anti-tipping kit (B) from back cover and drill 3 holes in the wall that align with the holes on anti-tipping-kit (B). Insert wall anchors (A).
3. Screw 3 wall screws (C) into anchors and slide fixture body onto screws.
4. Insert the (18) 4W type G bulbs (D) into the sockets.
5. Plug into proper electrical outlet and test the light.
6. Installation is complete.

### CARE INSTRUCTIONS:

Do not use polishes or cleaners on your lamp.  
JUST WIPE CLEAN WITH SOFT CLOTH.