

RH BABY & CHILD

EMERSON UPHOLSTERED HEADBOARD INSTRUCTIONS

PARTS INCLUDED

A [1] HEADBOARD

B [1] PRE-ASSEMBLED BED FRAME (NOT INCLUDED)

NO.	ITEM	DESCRIPTION	QTY.
1		Allen Bolts	6 pcs.
2		Flat Washer	6 pcs.
3		Spring Washer	6 pcs.
4		Allen Key	1 pcs.

ASSEMBLY INSTRUCTIONS

1. Hold headboard (A) upright and tilted slightly towards the faceplates of the pre-assembled bed frame (B).
2. Align the slot in the faceplate with the pre-drilled holes in the legs of the headboard (A).
3. Slide flat washer (2), spring washer (3) onto allen bolts (1) then insert allen bolts (1) into the top hole on legs, and use allen key (4) to tighten the bolts into legs, repeat for all pre-drilled holes.

CARE INSTRUCTIONS

1. Spot clean only with a soft, damp cloth.
2. Do not use abrasive cleanser.

IMPORTANT SAFETY INSTRUCTIONS

1. Please read all instructions carefully before assembling.
2. For your safety, assembly by two or more adults is strongly recommended.
3. Keep instructions for future use.
4. Use only vendor supplied hardware to assemble, using unauthorized hardware could jeopardize the structural integrity of the item.

