

# baby&child

## RESTORATION HARDWARE

### ACADEMY TASK CLIP LAMP

#### PARTS ENCLOSED:

- (A) CFL Bulb (1)
- (B) Socket (1)
- (C) Clip (1)

#### IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one prong is wider than other). If the plug does not fit securely into your outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way. This fixture has been rated for up to one (1) 40W max bulb. To avoid the risk of fire, do not exceed the recommended wattage.

#### WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity unless your fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the light bulb. Do not touch the bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE.

#### WARNING: STRANGULATION HAZARD

Keep cord at least 3 ft away from cribs, bassinets, and toddler beds.  
Keep out of reach of children under 3.

#### ASSEMBLY & INSTALLATION:

1. Carefully remove all parts from the box and remove the plastic covering.
2. Attach the lamp to the desk or table edge using the Clip (C), as shown.
3. Insert the CFL Bulb (A) into the Socket (B).
4. Plug into the proper electrical outlet and test lamp.
5. Assembly is complete.

#### CARE INSTRUCTIONS:

Do not use polishes or cleaners on your fixture.  
Just wipe clean with a soft cloth.

