

AMIRA WIDE DRESSER TOPPER

MARNING:

FALL HAZARD - To prevent death or serious injury from falls, always keep child within arm's reach

NEVER LEAVE CHILD UNATTENDED and always use restraining system. This changing table is intended for use with children weighing up to 30 pounds.

Do not use the Amira Wide Dresser or Amira Wide Dresser Topper if damaged or broken.

Customer Service- If you are missing parts or have any questions about this product, please contact us at: 1-800-762-1751

IMPORTANT SAFETY INSTRUCTIONS:

Please read all instructions before use of the Wide Dresser or Wide Topper. For your safety, assembly by two or more adults is recommended. Professional installation recommended. Keep instructions for future use.

PRE-ASSEMBLY:

The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions. Remove all parts and hardware from the box and lay out on a carpeted or scratch-free work surface. The shipping box provides an ideal work surface. Do not dispose of any contents until assembly is completed to avoid accidentally discarding small parts or hardware.

Use the parts on the hardware list to identify and separate each of the pieces included prior to starting assembly. Note: Do not fully tighten the screws until all parts are in place. Failure to follow these instructions may cause the screws to misalign during assembly.

If using power tools to aid in assembly please use caution. Power tools can damage hardware or split wood

HARDWARE INCLUDED:

A [2] Mending Plates




B [4] Phillips Head Screws



ASSEMBLY INSTRUCTIONS:

To connect Amira Wide Dresser Topper (C) to Amira Wide Dresser (D), place (2) Metal Brackets (A) over the predrilled holes on back of Wide Dresser and secure with [4] Phillips Screws (B). After installing Metal Brackets on Wide Dresser (D), please decide with the customer the left or right facing of the wide topper and place Amira Wide Topper (C) on the top of Wide Dresser(D) and check the distance on both side to make sure the dresser topper is centered correctly, mark the back of the topper to make pre-drilled holes first and secure the metal brackets to back of the Wide Topper (C) with screws.



- 1. Dust often using a clean, soft, dry lint-free cloth.
- 2. Blot spills immediately, and wipe with a clean, damp cloth.
- 3. We do not recommend the use of chemical cleansers, abrasives, or furniture polish on our lacquered finish.

Page 2 of 2.