

## MONTCLAIR DRESSER TOPPER



**WARNING: FALL HAZARD** - To prevent death or serious injury from falls, always keep child within arm's reach, NEVER LEAVE CHILD UNATTENDED and always use restraining system.

This changing table is intended for use with children weighing up to 50 pounds. Montclair Dresser Topper will be used with Montclair Dresser (sold separately) with size 42" W x 18.5" D x 34.75" H. Cushion pad size is 32"Lx16"Wx4"H.

Do not use Montclair Dresser Topper if it is damaged or broken.

Customer Service - If you are missing parts or have any question about this product, please contact us at: 1-800-762-1751.

### IMPORTANT SAFETY INSTRUCTIONS:

Please read all instructions before use of the dresser or topper.  
For your safety, assembly by two or more adults is recommended.  
Keep instructions for future use.

### PART LIST

- A. [1] MONTCLAIR DRESSER TOPPER
- B. [1] MONTCLAIR DRESSER
- C. [2] METAL BRACKET
- D. [8] PHILLIPS WOOD SCREW

### TOPPER ASSEMBLY INSTRUCTIONS

Place the dresser topper [A] on top of the dresser [B], and check the distance on both sides to make sure the wide topper is centered correctly. Secure the metals brackets [C] to the back of the dresser [B] and to the back of the topper [A] with screws [D].

### CARE INSTRUCTIONS:

- Dust often using a clean, soft, dry lint-free cloth.
- Blot spills immediately, and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives, or furniture polish on our lacquered finish

