



baby&child

RESTORATION HARDWARE

HENDRICK TABLE LAMP

PARTS ENCLOSED:

- (A) LAMP BASE
- (B) SOCKET
- (C) SADDLE
- (D) CFL
- (E) HARP
- (F) SHADE (NOT INCLUDED)
- (G) FINIAL
- (H) CORD



IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other).

If the plug does not fit securely into your outlet, do not force it-contact a professional electrician.

Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to one (1) 60W-type A bulbs.

To avoid the risk of fire, do not exceed the recommended wattage.



WARNINGS:

All the wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity until your fixture is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the light bulb.

Do not touch the bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from it bulb.

THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE.

WARNINGS: STRANGULATION HAZARD

Keep cord at least 3 ft away from cribs, bassinets, and toddler beds.

Keep out of reach of children under 3.

TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Put CFL 13 Watts (D) on socket (B) of Lamp Base
3. Put Harp (E) on Saddle (C)
4. Put Shade (F) on Harp (E) Tighten using Finial (H)
5. Plug the cord (H) into proper electrical outlet and test the lamp.
6. Installation is complete.

CARE INSTRUCTIONS :

Do not use polishes or cleaners on your lamp. just wipe clean with a soft cloth.