



baby&child

RESTORATION HARDWARE

CLASSIC TACK LINEN MEMORY BOARD (30" x 40")

PARTS INCLUDED

MEMORY BOARD




NO.	ITEM	DESCRIPTION	QTY
1		Screw	4 pcs.
2		Plastic Anchor	4 pcs.

ASSEMBLY INSTRUCTIONS

A) Wall Mounting

1. Unpack all parts, and place them on a protected work surface.
2. Drill small holes on each point location on the wall. Each hole should be just large enough to accommodate plastic anchor (2).
3. Insert the plastic anchor (2) and screw (1) into the holes on the wall.
4. Place the memory board with keyhole onto screw (1)
5. Installation is complete.

A:



CARE INSTRUCTIONS

1. To clean, use a soft dry or damp cloth.
2. Do not use abrasive cleanser.

IMPORTANT SAFETY INSTRUCTIONS

1. These instructions are provided for your safety. It is important that they are read carefully and completely before installation of the fixture. Professional installation is strongly recommended.
2. Check with a professional to ensure your wall can tolerate a fixture weighing 21 lbs.
3. For your safety, it is recommended that two people hang the fixture.