





**PARTS ENCLOSED:**

NO.	ITEM	DESCRIPTION	QTY.
A		Finial	1 pc
B		Harp	1 pc.
C		Bulb	1 pc. T3

**PALMER TABLE LAMP**



**IMPORTANT SAFETY INSTRUCTIONS :**

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated up to (1) 13 W CFL bulb or (1) 40 W standard bulb. To avoid the risk of fire, do not exceed the recommended wattage.

**WARNINGS :**

All wires are connected. When unpacking, be careful not to pull wire as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb.

Keep flammable materials away from the lit bulb.


**DO NOT REMOVE THE CARDBOARD INSULATOR SURROUNDING THE SOCKET**  
THIS IS NOT A TOY AND THE PRODUCT HAS NO PLAY VALUE

**ASSEMBLY INSTRUCTIONS**

1. Please make sure that you have all parts and hardware indicated above before you start assemble this item
2. This item should be assembled on a soft surface to prevent scratching of the finish during assembly.
3. This item may require periodic tightening.

**TO ASSEMBLE:**

1. Carefully remove all parts from the box and remove all plastic covering.
2. Place the lamp base (F) on the tabletop carefully.
3. Insert Harp (B) into the Saddle (E).
4. Insert the CFL bulb (C) , into threaded socket (D).
5. Place the Shade (Sold Separately ) on Finail Plate. Attach the finial (A) and tighten to secure the shade.
6. Plug into proper electrical outlet and test fixture.
7. Assembly is complete.



### Shade Instruction

\* Use only top and bottom open shade for 40 Wt. lamps.

R = Critical Radius =  $2\frac{1}{2}$ " Minimum

H = Critical Height =  $\frac{3}{4}$ " Minimum

CD = Cylinder Dia =  $3\frac{1}{4}$ " Minimum

### CARE INSTRUCTIONS

1. Dust often using a clean, soft, dry lint-free cloth.
2. Blot spills immediately.
3. We do not recommend the use of chemical cleansers, abrasives, or furniture polish.

\* Don't put the shade in this position

\* Use either metallic or any other slow burning material for the shade.