

RH

BABY&CHILD

CELESTIAL LINEN MOON LAMP - ASSEMBLY INSTRUCTIONS

PARTS ENCLOSED:

- (A) Bulb (1)
- (B) Socket (1)
- (C) Butterfly screw (1)

IMPORTANT SAFETY INSTRUCTIONS:

For safety purposes, this lamp is equipped with a polarized plug (one prong is wider than other). If the plug does not fit securely into your outlet, do not force it - contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.

This fixture has been rated for up to (1) 60-Watt maximum Type B standard incandescent lightbulb (not included) or one (1) 13-Watt maximum compact fluorescent lightbulb (not included) or one (1) 4-Watt maximum LED lightbulb (included).

To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection may result. Do not connect electricity unless your fixture is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it cool prior to replacing the lightbulb.

Do not touch the bulb when fixture is turned on or look directly at lit bulb.

Keep flammable materials away from lit bulb.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.



WARNING: STRANGULATION HAZARD

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds.

Keep out of reach of children under 3 years of age.

ASSEMBLY & INSTALLATION:

1. Carefully remove all parts from the box and remove the plastic coverings.
2. Secure the Socket (B) using the Butterfly Screw (C), as shown.
3. Insert the Bulb (A) into the Socket (B). Turn bulb clockwise to secure.
4. Plug into the proper electrical outlet and test lamp.
5. Assembly is complete.

CARE INSTRUCTIONS:

Do not use polishes or cleaners on the lamp.

Wipe clean with a soft, dry cloth.

